



Equator™ 300 versatile gauge

www.renishaw.com/gauging

Equator 300



Equator 300 Extended Height



Working volume (WV)	XY	Ø300 mm
	Z	150 mm
WV height from base*	55 mm	
Machine weight	25 kg	
Dimensions (WxDxH)	570 mm x 500 mm x 700 mm	

Working volume (WV)	XY	Ø300 mm
	Z	150 mm
WV height from base*	205 mm	
Machine weight	27 kg	
Dimensions (WxDxH)	570 mm x 500 mm x 850 mm	

* The position of the working volume in the Z direction depends on the length of the stylus. For example, the dimensions shown above are when using an SP25 with a 21x5 stylus. When using a 75 x 8 stylus on the EQ 300 standard height, the working volume boundary starts at the fixture plate.

Specification

Comparison uncertainty*	±0.002 mm
Probe type - scanning	Renishaw 3-axis SP25 analogue scanning
Maximum scanning speed (SP25)	200 mm/s
Scanning rate (SP25)	1000 points/s
Probe type - touch-trigger	Renishaw 3-axis TP20 kinematic touch-trigger
Recommended touch speed (TP20)	10 mm/s
Maximum movement speed	500 mm/s
Scale resolution	0.0002 mm
Fixturing requirement*	±1 mm
Machine air supply requirement	No air required
Operating temperature	+5 °C to +50 °C
Storage temperature	-25 °C to +70 °C
Relative humidity operating range	Maximum 80 %RH at 40 °C, non condensing
Machine electrical supply requirements	100-240 V AC ±10 %, 50-60 Hz
Maximum power consumption**	190 W
Typical power consumption***	80-100 W
Fixture plate	305 mm x 305 mm aluminium
Maximum workpiece weight	25 kg

* The process of measuring on an Equator involves defining a series of gauge points on the component surface. Periodic calibration of a master part on a CMM establishes datum values for each gauge point. The same gauge points on the same master part are measured on Equator, 'mastering', to establish a correlation with the certified CMM. Subsequently, a regular 're-mastering' process is used to account for changing environmental conditions. Size and position measurements made immediately following re-mastering will have a comparison uncertainty of ±0.002 mm relative to the certified measurements of the master part. This specification applies where each part is fixtured to within 1 mm relative to the master part.

** Peak consumption at power up.

*** 3-axis system typical consumption based on taking touch points under DCC control.

Equator 300 ordering



A - EQ 3 3 - 1 S 1 1 A

Part number type

A = Assembly

Series

EQ = Equator with SP25

EH = Equator Extended Height with SP25

TQ = Equator with TP20

TH = Equator Extended Height with TP20

Working volume

3 = 300 mm diameter

Number of axes

3 = 3 axes

Controller standard

1 = Controller kit with Organiser and MODUS (Operator version)

2 = Controller kit with Organiser and MODUS (Programmer version)

Manual functions

S = Stop button

J = Joystick kit

B = Button interface and stop button kit

Fixture plate hole size

1 = M6 41 holes

2 = M8 41 holes

3 = Imperial ¼ in. 41 holes

4 = Imperial ¼ in. 441 holes modular fixture plate

5 = M6 441 holes modular fixture plate

6 = M8 441 holes modular fixture plate

Extended warranty

0 = Without extended warranty

1 = 1 year extended warranty (covering year 2 of ownership)

Power cables (x 2 per system)

A = UK; B = EU and Korea; C = USA, Mexico, Canada, Japan and Taiwan; D = China; E = South Africa and India;

F = Switzerland; G = Denmark; H = Australia; I = Israel; J = Italy and Chile; K = Brazil

For worldwide contact details, visit www.renishaw.com/contact

RENISHAW HAS MADE CONSIDERABLE EFFORTS TO ENSURE THE CONTENT OF THIS DOCUMENT IS CORRECT AT THE DATE OF PUBLICATION BUT MAKES NO WARRANTIES OR REPRESENTATIONS REGARDING THE CONTENT. RENISHAW EXCLUDES LIABILITY, HOWSOEVER ARISING, FOR ANY INACCURACIES IN THIS DOCUMENT.

